### **Development Services**

#### From Concept to Construction







ΔP	PFΔ	I SI	IN/IN	//ARY
$\neg$	$\Gamma \sqcup \Lambda$	L OL	/ I V I I \	////////

Status:	Decision	Rendered -	Held over from	n ID <i>22</i> 072. iten	n #1 (11/6/19) for addit	ional information

Appeal ID: 22238	Project Address: 1120 SE Morrison St
Hearing Date: 12/18/19	Appellant Name: Patrick Turina
Case No.: B-008	Appellant Phone: 5038472185
Appeal Type: Building	Plans Examiner/Inspector: Maureen McCafferty
Project Type: commercial	Stories: 7 Occupancy: A-3, B, R-2, S-1, S-2 Construction Type: I-A, III-A
Building/Business Name: Modera Morrison	Fire Sprinklers: Yes - Throughout
Appeal Involves: Erection of a new structure,other: Additional information for appeal 22072, item 1	LUR or Permit Application No.: 19-131007-EA
Plan Submitted Option: pdf [File 1] [File 2] [File 3]	Proposed use: Multi-Family Residential and Retail

#### APPEAL INFORMATION SHEET

#### Appeal item 1

Code Section	2019 OSSC, 602.3 Ty	ype III
--------------	---------------------	---------

#### Requires

Type III construction is that type of construction in which the exterior walls are of noncombustible materials and the interior building elements are of any material permitted by this code. Fire-retardant-treated wood framing and sheathing complying with Section 2303.2 shall be permitted within exterior wall assemblies of a 2-hour rating or less.

#### **Proposed Design**

The proposed design is a mixed-use building with 5 stories of Type III-A construction over 2 stories of Type I-A construction. The Type III-A construction primarily houses R-2 occupancy apartment units, with accessory S-1 and A-3 occupancies. Proposed exterior walls at the Type III-A construction are to be framed with non-fire-retardant-treated (non-FRT) wood. While OSSC 602.3 limits wood framing at Type III-A exterior walls to fire-retardant-treated (FRT) wood, the City of Portland's Code Guide OSSC/6/#4 (Type III Code Guide) allows non-FRT wood framing at Type III-A exterior walls, provided the 17 conditions listed in the code guide are met.

Condition #4 listed in the Type III Code Guide requires sacrificial studs at the sides and top of all openings in exterior walls for doors, windows, and wall-mounted HVAC units and louvers.

Condition #17 also references sacrificial studs, as it requires exterior wood framing be constructed as specified in the details included in the guide. The proposed design omits sacrificial studs at exterior wall openings.

Condition #11 listed in the Type III Code Guide limits the distance from the top of the roof parapet to the lowest required fire apparatus setup point to 75 feet. The parapet height of the proposed design exceeds this limit at several locations along the perimeter of the building. Please see

attached exhibits 1A and 1B for parapet heights. Please note that the proposed design will meet all conditions listed within the "Alternate to Aerial Fire Apparatus Roads" section of "Portland Fire & Rescue: Fire & Life Safety Requirements for Fire Department Access and Water Supplies."

To offset these unmet Type III Code Guide conditions, the proposed design includes mineral wool insulation friction fit between wood studs to fill the entire 6" nominal wall cavity in lieu of fiberglass insulation. The mineral wool insulation contributes to an increased level of fire resistance of the wood-framed exterior walls. Please see attached exhibit 1C for proposed wall assemblies.

Reason for alternative Regarding Code Guide condition #4, the proposed wall assemblies do not require sacrificial studs to achieve a higher level of fire-resistance than required by code. A non-FRT wood framed assembly using mineral wool insulation without sacrificial studs outperforms an FRT wood framed assembly using fiberglass batt insulation and sacrificial studs. Please see attached white paper analysis for more information.

> Regarding condition #11, the site features an approximate 16-foot grade drop from the northeast corner to the southwest corner. The parapet height at the high corner of the site is less than 75'-0", but it exceeds that limit elsewhere due to the substantial grade change. Even though the Type III Code Guide condition #11 cannot be met, FRT wood framing is still to be avoided due to environmental and structural reasons listed below.

> The process of pressure-impregnating fire-retardant chemicals into wood to achieve FRT criteria has a negative environmental impact. Additionally, there are concerns regarding the health impact to the building occupants from long term exposure to the chemicals used in pressure impregnation. Unlike the chemical FRT process, mineral wool is made from inorganic fiber that does not have an adverse impact on the environment or occupant health.

> The FRT process also reduces the structural strength of wood that must be accounted for in the structural design. The presence of impregnated fire retardant degrades the typical wood strength properties, often resulting in increased cracks and splits in the framing over time. This reduction in strength and bearing capacity requires structural members to be oversized and requires an increase in the overall amount of framing throughout the project.

The attached white paper analysis provides a fire analysis that supports the use of mineral wool insulation in the wall cavity of untreated wood stud framing as an alternative to FRT wood stud framing permitted by the OSSC section 602.3. The analysis compares FRT wood framed wall assemblies with non-FRT wood framed wall assemblies. The analysis is based on published temperature data from full scale testing of multiple configurations of fire rated stud walls. The analysis concludes that untreated wood framed walls with ComfortBatt/Roxul mineral wool insulation will outperform FRT wood framed walls without such insulation.

We believe the proposed exterior wood-framed walls provide higher fire-resistance ratings than those outlined in the Type III Code Guide, even as conditions #4 and #11 are not met. The inclusion of mineral wool contributes to an increased overall building safety, and therefore we kindly request that this appeal be granted.

Please see granted precedent appeal 18728.

#### APPEAL DECISION

Use of non-fire resistant treated wood in exterior walls of Type III construction with mineral wool insulation: Granted as proposed.

The Administrative Appeal Board finds that the information submitted by the appellant demonstrates that the approved modifications or alternate methods are consistent with the intent of the code; do not lessen health,

safety, accessibility, life, fire safety or structural requirements; and that special conditions unique to this project make strict application of those code sections impractical.

Pursuant to City Code Chapter 24.10, you may appeal this decision to the Building Code Board of Appeal within 90 calendar days of the date this decision is published. For information on the appeals process, go to www.portlandoregon.gov/bds/appealsinfo, call (503) 823-7300 or come in to the Development Services Center.



Sheets 51, 52 vs. sheets 4, 5


1A



MODERA MORRISON | EA 19-131007 DA TYPE III CODE GUIDE

1" = 30'-0"

SERA






MODERA MORRISON | EA 19-131007 DA

1" = 30'-0"

SERA


1B



3 <u>LEVEL 7</u> 1" = 50'-0"



2 <u>LEVELS 3-6</u> 1" = 50'-0"



1. RATING IN ACCORDANCE WITH CITY OF PORTLAND CODE GUIDE - TYPE III CONSTRUCTION - OSSC/6/#4 2. CONTINUE ASSEMBLY TO UNDERSIDE OF SUB-FLOORING AND ROOF SHEATHING WHERE 6x12 WOOD BLOCKING IS NOT PRESENT.

1C

# EXTERIOR WOOD FRAME ASSEMBLIES 3" = 1'-0"

MODERA MORRISON | EA 19-131007 DA TYPE III CODE GUIDE



# CODE UNLIMITED, LLC

# Modera Morrison White Paper Fire Analysis of FRT Wood Alternate

Prepared by: Code Unlimited

Address: 13515 SW Millikan Way, Beaverton, OR 97005

Date: 12/11/2019

### **Table of Contents**

1.	Ove	erview	. 3		
1	.1	Project Overview	. 3		
1	.2	Executive Summary	.3		
1	.3	Applicable Codes and Standards	. 4		
1	.4	Additional References	. 4		
2.	Prop	posed Wall Assembly	. 5		
3.	Roc	k Wool Use Prescriptively Permitted in Current Code	. 5		
4.	Performance Based Analysis and Verification6				
5.	'				
6.	Additional Benefits				
7.	Con	oclusion	16		
ΑP	APPENDIX A				

#### 1. OVERVIEW

#### 1.1 Project Overview

Modera Morrison is a new project to be constructed at 1120 SE Morrison Street in Portland, OR. It is under the jurisdictional review of the City of Portland. This seven-story building that consists of five stories of Type IIIA construction placed on top of two stories of Type IA construction. The building includes 247 residential units with parking, retail, and resident amenities. It will be fully protected throughout by automatic sprinklers, fire and smoke detection and a fire alarm system.

Type IIIA construction requires that exterior walls be of noncombustible construction or of Fire Retardant Treated Wood (FRTW) construction. The project proposes to use wood without the Fire Retardant Treatment (FRT). There are significant structural and environmental benefits for this approach.

### 1.2 Executive Summary

Fire-retardant treated (FRT) wood framing is permitted by code within exterior Type III wall assemblies with a fire-resistance rating of a 2 hours or less. This is based on the improved fire performance of such wood compared to regular wood of same species. FRT of wood delays ignition and resists "flame spread" once ignited. The proposed design uses tightly packed rock wool insulation between non-treated wood framing members in lieu of Fire Retardant Treated Wood (FRTW) to achieve equal or better fire performance.

Over the last three years Code Unlimited has analyzed this particular issue, namely the use of non-FRT wood in place of FRTW on multiple projects. This has been driven by many stakeholders within the Pacific Northwest region; local and state governments, universities and other research groups, manufacturers, real estate developers, and design and construction industry professionals. This white paper is the most current knowledge on this subject, based on rigorous analysis, review, and input, from senior fire protection engineers and code experts within our company.

The white paper is structured to give the reader a detailed understanding of the code regulations that are driving this requirement along with excerpts from the International Building Code (IBC) commentary to clarify intent where necessary. We also provide other code citations where prescriptively the Oregon Structural Specialty Code (OSSC) and the IBC permits the use of rock wool (aka mineral wool) as a means to delay ignition or fire and flame migration. This is provided as documentation of established tradition. Many code provisions have evolved initially out of traditional construction practices and then undergo rigorous analysis and/or testing to substantiate its performance in those applications. This white paper follows that time tested path by including a rigorous performance analysis based on currently available test data in support of non-FRT wood in an exterior wall of a type IIIA construction building.

Our analysis found that the fire performance of a non-FRTW framed wall with rock wool insulation is equal or superior to a FRTW framed wall. We also found support for the argument that this approach reduces the potential for chemical exposure to the environment and to the occupants of these buildings compared to the current practice of using FRTW.

#### 1.3 Applicable Codes and Standards

#### Applicable Code or Standard

2019 Oregon Structural Specialty Code (OSSC)

2009 ASTME-84 Test Methods for Surface Burning characteristics of Building Materials – American Society for Testing and Materials

2007 ASTME E-119 standard Test Methods for Fire Tests of Building Construction and Materials – American Society for Testing and Materials

#### 1.4 Additional References

- <sup>1</sup> 2003 Ignition Handbook: Principles and Applications to Fire Safety Engineering, Fire Investigation, Risk Management and Forensic Science, Dr. Vytenis Babrauskas Fire Science Publishers
- <sup>2</sup> 2006 Performance of a Non-load Bearing Steel Stud Gypsum Board Wall Assembly: Experiments and Modelling, Samuel Manzello, Richard Gann, Scott Kukuck, Kuldeep Prasad, and Walter Jones - Building and Fire Research Laboratory (BFRL), National Institute of Standards and Technology (NIST), Weapons and Materials Research Directorate, US Army Research Laboratory, APG.
- <sup>3</sup> 2007 Analysis of Inter-laboratory Testing of Non-loadbearing Gypsum/Steel-Stud Wall Assemblies, William Grosshandler, Samuel L. Manzello, Alexander Maranghides Building and Fire Research Laboratory, Tensei Mizukami Center for Better Living
- <sup>4</sup> 1977 Effect of fire-retardant treatments on performance properties of wood. In: Goldstein, I.S., ed. Wood technology: Chemical aspects. Proceedings, ACS symposium Series 43. Washington, DC: American Chemical Society.
- <sup>5</sup> 1992 Charring Rate of Wood for ASTM E119 Exposure, Fire Technology Volume 28, Number 1, Robert H. White and Fric V. Nordheim
- <sup>6</sup> 1977 National Board of Standards Technical Note 945: An Investigation of the Fire Environment in the ASTM E 84 Tunnel Test
- <sup>7</sup> 2007 Performance of a non-load-bearing steel stud gypsum board wall assembly: Experiments and modelling", Samuel L. Manzello, et al, Fire and Materials (Issue 31, pp 297-310) (this is an updated version of reference #2 above)
- <sup>8</sup> 2016 Calculating the Fire Resistance of Exposed Wood Members, Technical Report No 10, American Forest & Paper Association, Inc, American Wood Council, 1111 19th St., NW, Suite 800, Washington, DC 20036

<u>www.codeul.com</u>

- <sup>9</sup> 2015 A Model for predicting heat transfer through insulated steel-stud wall assemblies exposed to fire, Sultan, M. A.; Alfawakhiri, F.; Bénichou, N., Fire and Materials 2001 International Conference, San Francisco, January 22-24, 2001, pp. 495-506
- <sup>10</sup> 2010 Wood Handbook, Wood as an Engineering Material, Chapter 17 Fire Safety, Robert H. White and Mark A. Dietenberger, Forest Product Laboratory, United States Department of Agriculture Forest Service, Madison Wisconsin

#### 2. PROPOSED WALL ASSEMBLY

The proposed design is to provide a 2-hour exterior wall assembly that consists of untreated wood stud framing with two layers of 5/8" thick type X gypsum board on the interior and one or two layers (depending on the fire separation distance) of 5/8" type X gypsum sheathing on the exterior side of the wall. Rock wool insulation will be friction fit between studs to fill the entire 6 inch nominal wall cavity. Details of the proposed wall sections are in the attached Appendix A. The conclusions of this report are limited to the proposed exterior wall types included in Appendix A of this white paper.

§705.5 of the 2019 OSSC states the exterior wall assembly is required to be rated for fire exposure from the interior only if the fire separation distance (FSD) is greater than 10 feet, and is required to be rated from both sides if the FSD is less than or equal to 10 feet from the property line. Per §705.5, the proposed assembly includes one layer of 5/8" thick type X gypsum board on the exterior side where the FSD is greater than 10 feet, and two layers of 5/8" thick type X gypsum board on the exterior side where the FSD is less than or equal to 10 feet from the property line.

#### 3. ROCK WOOL USE PRESCRIPTIVELY PERMITTED IN CURRENT CODE

The 2019 OSSC section 602.3 for Type III, exterior wall construction, permits the use of fire-retardant treated wood (FRTW) in lieu of non-combustible materials.

Rock wool barriers have been allowed in the codes as a means to retard or prevent the ignition of wood in concealed spaces, for some time now:

- 1. OSSC 803.15.1.1 allows untreated wood to be used for furred walls or ceilings where Non-Combustible construction is required when the cavity is filled with rock wool insulation.
- 2. OSSC 718.2.1(7) allows rock wool batts to be used as fireblocking to cut off concealed draft openings.
- 3. OSSC 718.3.1 permits the use of rock wool batts as an approved draft stopping material.
- 4. ORSC 316.5.3 permits the use of 1.5 inch thick rock wool to satisfy the requirements for an ignition barrier.
- 5. NFPA 13 section 8.15.1.2.17 allows untreated wood joist to be treated as FRT wood when the cavity is filled with rock wool insulation.

6. OSSC 722.6 contains procedures by which the fire resistance ratings of wood assemblies are established by calculations.

IBC Section 722.6 Commentary states:

"Rock wool insulation provides additional protection to wood studs by shielding the studs from exposure to the furnace, thus delaying the time of collapse."

OSSC table 722.6.2(5) allows glass fiber, or rock wool, or cellulosic fill within stud cavity prescriptively to increase the fire resistance of a wall assembly by 15 minutes.

7. IBC Section 602.2 Commentary:

"Fire Retardant-treated wood (FRTW), although combustible, is permitted in limited uses in building of Type I and Type II construction... it is not assumed to be fire-resistance rated, and generally does not afford any higher fire-resistance rating than untreated wood material."

#### 4. PERFORMANCE BASED ANALYSIS AND VERIFICATION

The list of prescriptive provisions in section 3 establishes the code history use of mineral wool insulation to improve the fire performance of wood wall and ceiling assemblies. These provisions are an outgrowth of tradition and historical construction practice. The values assigned to these are generic values, based on historical data. These are valuable in establishing precedence and intent of the code requirements. Our analysis is based on the full scale test data documented in the research papers #2, #7, and #9 listed in section 1.4 in this white paper. The remaining references #1, #3, #4, #5, #6, #8, and #10, provide supporting evidence for the methodology used in this analysis as well as some other key metrics used in the analysis. The full scale testing was performed with 4 inch metal stud wall assemblies, while the wall assemblies analyzed in this white paper are nominal 6 inch wood assemblies. Wood is a non-conductor of heat and superior performer to metal within the context of this analysis. Our test data includes wall assemblies with both fiberglass and mineral wool insulation within the stud cavity. Mineral wool outperforms fiber glass insulation at higher temperatures. In these two cases as well as in all other cases, our analysis takes the conservative value when there are multiple data points available.

Building structural component fire performance is predicated on the type of fire exposure. Most commonly fire from combustible building contents or furnishings, expose the components such as walls of structural frame to heat from the fire, causing loss of structural integrity of the wall and its eventual collapse. The point at which the load-bearing components of a Type III wall (in this case, the wall studs) are exposed to heat from the fire, the building would have long since been evacuated and the space become untenable, as the temperature required to breach the gypsum board membrane would be beyond survivability. In this case, the sole concern is for the preservation of structural stability and protect firefighters and adjacent structures. The studs of the walls provide the necessary structural, load bearing capability to support the exterior wall. Gypsum board or other sheathing is solely relied on to provide resistance to the fire exposure in order to protect the load bearing members, its contribution to the structural strength of the wall is negligible. The Commentaries to section 722.6 of the IBC state "It is assumed that once the structural members fail, the entire assembly fails."

OSSC section 602.3 defines Type III construction as "that type of construction in which the exterior walls are of noncombustible materials and the interior building elements are of any material permitted by this code. *Fire-retardant-treated wood* framing complying with Section 2303.2 shall be permitted within *exterior wall* assemblies of a 2-hour rating or less."

Fire retardant treatment of wood does not prevent the wood from decomposing and charring under fire exposure. The rate of fire penetration through treated wood approximates the rate through untreated wood. Fire-retardant-treated wood used in walls can slightly improve fire endurance of these walls, but, most of this improvement is associated with the reduction in surface flammability rather than any changes in charring rates




Figure 17–1. Heat release curves for untreated and FRT plywood exposed to 50-kW/m² radiance.

Fig.1. E84 Test Comparison (Wood Handbook Chapter 17)

The surface layer of FRTW is a fire retardant treatment that slows ignition by interfering with heat transfer to the material and chemically interferes with combustion. It does so by converting combustible gases and tars to carbon char at temperatures below 550°F<sup>4,10</sup> and releases carbon dioxide and water vapor which dilute the combustible gases. However, above temperatures of 550°F, outgassing and pyrolysis effects exceed the limits whereby ignition is interfered and FRT heat release and burning rates compare to untreated wood of the same variety. Charts of the ASTM E84 (Standard Test Method for Surface Burning Characteristics of Building Materials) heat release rates (Fig. 1) show that, at about 420 seconds (7 minutes), the heat releases rate (HRR) for FRTW and non-FRTW are virtually identical, indicating that, after the fire retardant treatment has been exhausted, the non-FRT and FRT wood studs will perform similarly.

In a 2-hour fire rated wall, once the gypsum layers are compromised, the fire is free to attack the exposed studs. However, charring and consumption of the studs begins before failure of the gypsum membrane, as heat is conducted to the edge face of the studs and to the stud wall cavity by conduction through the gypsum board. In the stud wall cavity, the temperatures are already well over the autoignition temperature of wood and the point at which FRTW becomes ineffective (550°F) by the time the two gypsum board layers have been compromised. Although the standard stud begins charring sooner than the FRTW stud, total time to fail for the

standard stud assembly is much longer due to the insulative effects of the rock wool, slowing progressive char over the longer dimension (side) faces of the stud by preventing heat transfer to the stud cavity.

Above 550°F, FRTW studs behave similar to a standard wood studs and charring continues until it fails in load. Char rates for softwoods such as used in framing lumber are at an average rate of 1.5 in/hr 8. By calculating the heated perimeter of the wood studs for an uninsulated, code-accepted FRTW stud and a rock-wool insulated standard stud, and using the average char rate, a time to failure of the two studs can be determined.


The effective heated perimeter of a 2" x 6" nominal FRTW stud is 12.5 inches at the point of its ignition. The effective heated perimeter of a rock wool insulated stud is only 1.5 inches at the same point, although the point of ignition is approximately 7 minutes earlier due to the effects of FRT and the delay of ignition of the FRTW stud. As the studs are consumed by charring, the 3-sided attack<sup>8</sup> on the FRTW stud results in much more material loss due to charring and more rapid reduction in load-bearing capability. While there is some charring of the sides of the standard stud, especially nearest the exposed edge, the insulative properties of the rock wool significantly slow charring and loss of material.

OSSC Table 722.6.2(2) states that the time assigned for contribution of the wood frame to fire resistance is 20 minutes. Within that time, the fire is assumed to consume sufficient of the stud framing to compromise its structural strength such that it fails under load. Thus it was assumed that, once the FRTW studs reach the point where the fire retardant treatment no longer interferes with charring, the stud will have 20 minutes of load-bearing capability before failure. This occurs with approximately 25% of the original stud cross-section remaining after charring. A similar failure point was used for analysis.

OSSC Table 722.6.2(5) notes that "Additional Protection" can be provided to a wall for fire rating purposes by the addition of rock wool insulation at a specified minimum density. The Commentaries for IBC section 722.6 note that "Rock wool insulation provides additional protection to wood studs by shielding the studs from exposure to the furnace, thus delaying the time of collapse." Rock wool does this by insulating the sides of the studs from direct heat and flame exposure and by interfering with flame spread by conduction, radiation and convection within the wall cavity. In this respect, the assembly is superior to FRTW with only fiberglass insulation, in that its ability to interfere with ignition is not compromised by high exposure temperatures. Rock wool has a melting point of 2150°F and can withstand a 4 hour test per ASTM E119 time-temperature curve, where the fire temperature reaches a maximum temperature of 2000°F, well above the temperatures expected in a flashover fire condition.

Unlike a simple, 2-hour rated FRTW stud wall, rock wool provides protection on the sides of the studs, ensuring the main route of burn-through to be in the longest dimension of the lumber (See Fig 4-6). In FRTW, fire attack, once the thermal membrane has been compromised, is on three sides of the stud and burn through of the stud is much more rapid. Use of rock wool insulation is specified as it has greater refractory qualities, higher installed density and remains in place long after fiberglass insulation has melted away.

Clearly, there is an advantage to the use of rock wool in the wall that an ordinary FRTW assembly does not match.



#### Legend

SL - Gypsum Board Single Layer BL - Gypsum Board Base Layer FL - Gypsum Board Face Layer Std. - Stud Cav. - Cavity Exp. - Exposed Side Unexp. - Unexposed Side Fire - Directly exposed to furnace

Figure 2: Time vs temperature curve – Double Layer 5/8" Gypsum Board, Studs 16" O.C.9

Note: Line (open dots) for temperature at inner surface of base layer, exposed side. This is temperature of stud cavity/edge of stud.

#### **Derivation Calculation**

Utilizing test data from reference document #9, (equation #10) and Fig. 2 above. The calculated stud surface temperature can be derived and graphed.

Eq. 10<sup>9</sup>

$$T_{m}^{j+1} = T_{m}^{j} + \frac{\Delta t}{(\rho_{i}c_{i})_{m}^{j}(\Delta y)^{2}} \left\{ \left[ \frac{(k_{i})_{m-1}^{j} + (k_{i})_{m}^{j}}{2} \right] (T_{m-1}^{j} - T_{m}^{j}) - \left[ \frac{(k_{i})_{m}^{j} + (k_{i})_{m+1}^{j}}{2} \right] (T_{m}^{j} - T_{m+1}^{j}) \right\}$$

The calculated time to autoignition temperature for several depth increments into the mineral wool insulation (long direction of stud) are displayed below. (See Fig. 2A)




Figure 2A: Time vs Stud Surface Temperature curve – Calculated per Eq. 10.9

### 5. FIRE RESISTANCE COMPARISON




Figure 3: FRTW and Mineral Wool Stud Walls

Note: Figures 3-6 do not show composition of the exterior (non-fire exposed) side, as other constructions, allowed by code for non-fire exposed assemblies, may be used. All wall types shall be 2-Hr rated as shown in Appendix A. For the fire separation distance less than 10 feet, an additional layer of 5/8" type X gypsum board is required on the exterior side of the wall.




Fig 4: FRTW and non-FRTW Stud Wall at 60 Minutes After Fire Exposure of Gypsum Board Wall




Figure 5: FRTW and Non-FRTW Stud Walls at 70 Minutes After Fire Exposure of Gypsum Board Wall Point of FRTW Wall Failure




Figure 6: Non-FRTW Stud Wall at Failure at 112 Minutes – Reduced Cross Sectional Area Equivalent to FRTW at Failure

Charring and loss of load-supporting cross-section of the wood studs begins at approximately 43 minutes after exposure of the wall to fire, as heat conducts through the gypsum board and the temperature at the inside face of the gypsum board wall reaches the autoignition temperature of wood. Ignition of the FRTW is delayed by approximately 7 minutes by the action of the fire retardant treatment. By approximately 50 minutes after exposure, both studs are experiencing charring.

At 60 minutes after exposure, approximately 50% of the allowable cross-section of the FRTW stud has been consumed by charring. Somewhat less (27%) of the insulated non-FRTW stud has been consumed at the same point, due to the effects of rock wool of rock wool in limiting heat transfer to the wood.

At 70 minutes, the FRTW has lost sufficient cross section that it fails in load. At this point, approximately 25% of the original FRTW stud cross-section remains. However, only 39% of the insulated stud has been consumed.

At approximately 112 minutes, charring of the insulated non-FRTW stud reaches the point at which less than 25% of the original cross-section remains and the stud fails.

The table below provides a comparative analysis that clearly shows that standard wood framing with rock wool insulation performs better than FRT wood framing under fire conditions.

Time Interval (minutes)	Description	FRTW Stud Reaction	Standard Stud with Rock Wool Insulation Reaction
t = 0	Gypsum board face of wall is first exposed to flames/heat, interior of stud wall at ambient temperature	None	None
t = 43	Temperature at edge face of stud attached to gypsum board exceeds autoignition point of wood (500°F), stud cavity of FRTW exceeds autoignition point of wood (500°F) (See Fig. 2)	FRT of wood stub inhibits ignition of FRT studs	Charring begins on narrow edge of stud (1.5" wide)
t=50	Chemical and mechanical inhibition of ignition of FRT wood exhausted	Charring begins on narrow edge of stud (1.5" wide) and along both exposed long faces (5.5" wide each)	Charring along wide faces nearest to the gypsum board (Autoignition temperature boundary at 2.75" depth)
t=60		Charring has consumed 50% of allowable	Charring has consumed approximately 27% of allowable (Autoignition temperature boundary at 4.125" depth)
t =70		Char layer exceeds allowable, insufficient cross-section of stud available to support load, stud fails	Charring has consumed approximately 39% of allowable (Autoignition temperature boundary at full depth)
t = 112.6			Char layer exceeds allowable, insufficient cross-section of stud available to support load, stud fails

### 6. ADDITIONAL BENEFITS

1. Depending on the species, type of product (stud, joist, plywood, beam), and its application (wall, floor, roof), the strength originally associated with wood is reduced when treated with a fire retardant. Therefore, the FRTW manufacturer is required to provide strength adjustments based on the intended use of the wood. This reduction in strength must be factored in to the structural design of the building. The effective

spans and bearing capacity of the lumber is reduced, so beams are over-sized and more lumber is used in the project than required with standard studs. Hence non-treated wood consumes less of the available resources and is structurally stronger than FRTW.

- 2. The process of pressure-impregnating chemicals into wood to achieve FRT lumber has a negative environmental impact, due to increased use of virgin chemicals and more waste chemicals that needs to be treated before it is discharged in to the sewer system. Additionally, there are health impact concerns regarding to the occupants of the building from a long term exposure to the chemicals used in pressure impregnation. Unlike the chemical FRT process, rock wool is made from an inorganic fiber that does not have adverse impacts on the environment or individual health of occupants.
- 3. Due to the potential corrosion of steel, hot-dipped galvanized fasteners are required over standard zincplated type, when using FRT wood. Rock wool is made from inorganic fiber, it does not reduce the strength of the wood, and does not require hot dipped galvanized fasteners. Hence, it is a better alternative for the environment and overall structural design.

#### 7. CONCLUSION

Rock wool batt insulation will be friction fit between the 2x6 studs. Filling the entire depth of the wall cavity will provide better protection than FRT wood framing as permitted by OSSC 2303.2 and 603.2. The architect is proposing to use comfort batt insulation product by Roxul Company. The batt insulation will be 5.5 inches thick and will be friction fit within the stud cavity. This product is within the parameters of our analysis and the proposed wall assembly will exceed the performance of an FRT wood framed wall assembly. Code does not prohibit the use of better quality products than what is mandated; as this proposed assembly exceeds the base code criteria it will satisfy the code requirements.

Samir Mokashi Principal/Code Analyst



Franklin Callfas
Principal/Code Unlimited
Fire Protection Engineer
Code Unlimited




## Appendix A

**Proposed Wall Sections** 





Appendix A Figure 1: Typical Floorplan (Floors 3-7)



#### **NOTES**

1. RATING IN ACCORDANCE WITH CITY OF PORTLAND CODE GUIDE - TYPE III CONSTRUCTION - OSSC/6/#4 2. CONTINUE ASSEMBLY TO UNDERSIDE OF SUB-FLOORING AND ROOF SHEATHING WHERE 6x12 WOOD BLOCKING IS NOT PRESENT.

## EXTERIOR WOOD FRAME ASSEMBLIES

Appendix A Figure 2: Typical Exterior Wall Type